

Lab 4

## Assigning IP Address to a Network (with Server / DHCP)

1. Make a network similar to this and open the Server settings.



2. Open desktop and go to IP Configuration




**3.** In the "IP Address" field, type the following IP address: **192.168.1.1** and click enter, it'll automatically add a relevant subnet mask and in the "Default Gateway" type the IP Address of the router, or enter an IP Address which you'll then give to the Router (**192.168.1.2**).

Configuration		X
IP Configuration		
O DHCP	<ul><li>Static</li></ul>	
IP Address	192.168.1.1	
Subnet Mask	255.255.255.0	
Default Gateway	192.168.1.2	
DNS Server	0.0.0.0	


## **Computer Networks**

#### Rasikh Ali


4. Now, go to the "Services" tab and open "DHCP", here Click on the "serverPool" from list below



**5.** Now, just change the "Default Gateway" from 0.0.0.0 to the IP Address which is preserved to be set to Router / Router's IP (**192.168.1.2**) and Click on "ON" button for "Service" and click on Save and close it.



**6.** Hover over the Server to double-check if the IP and Gateway is assigned or not.




#### Rasikh Ali

- 7. Now, Assign the Router's IP (192.168.1.2) if you haven't already (follow previous steps of assigning IP to router)
- **8.** Now, click on the end device (PC/Laptop) and open its setting and go to "desktop".



**9.** From here, open the first option "IP Configuration"



10. Now, in here, just click on DHCP and let the "Magic Begin" It'll automatically assign an IP




- **11.** Then do the same (Step 8 to 10) for all the End Devices.
- 12. Afterwards, you can check if the IP is assigned to devices, (either by hover, or command prompt)

```
C:\>ipconfig

FastEthernet0 Connection:(default port)

Link-local IPv6 Address ... : FE80::240:BFF:FE67:E4A5
IP Address ... : 192.168.1.3
Subnet Mask ... : 255.255.255.0
Default Gateway ... : 192.168.1.2
```

**13.** Now to check if we can transfer message between end-devices or not, just open any end-device and open its Command Prompt, and type "**ping**" and afterwards type the **ip-address** of **target device**.



**14.** As there is **0% loss** that means, the connection was successful and message was sent successfully.

# Lab 4 - Task

## Task 1;

Design the network of "Lab-7" or "Lab-8" (2-3 rows of computers) Use: Server, Switch, Router, & End-Devices like Laptop/PC Assign them IP Address (Dynamically/DHCP) of any Network (or you can use network **192.168.1.0**)